


Assembly of actuating gear KB55/S/SS



• Starting condition



• Final condition

Note:

After complete adjustment of the release mechanism, set the stop cam to the actuating lever and fix it, secure with Ø5mm dowel pin!

